

MFP / Printer / Scanner							Update : 01/25/2010
No	Brand	Model Name	Windows 2000				
			Print	Scan	Card Reader	LPR*	
1	Brother	HL-2040	Pass	N/A	-	Pass	
2	Brother	MFC-3320CN	-	N/A	-	-	
3	Brother	MFC-3820CN	Pass	N/A	-	Pass	
4	Canon	MF3110	Pass	Pass	-	Pass	
5	Canon	MP150	Pass	Pass	-	Pass	
6	Canon	MX308	Pass	N/A	-	Pass	
7	Canon	Satera MF 4010	Pass	N/A	-	Pass	
8	Canon	Satera MF 4150	Pass	N/A	-	Pass	
9	Epson	CX4700	Pass	Pass	-	Pass	
10	Epson	PM-A950	Pass	Pass	-	Pass	
11	HP	Color LaserJet 2600n	Pass	N/A	-	Pass	
12	HP	Deskjet 3745	Pass	N/A	-	Pass	
13	HP	LaserJet 1010	N/S	N/A	-	N/S	
14	HP	LaserJet 1020	N/S	N/A	-	-	
15	HP	LaserJet 3330	Pass	N/A	-	Pass	
16	HP	Officejet 5610	Pass	N/S	-	Pass	
17	HP	Photosmart 3210	Pass	N/S	-	Pass	
18	HP	PSC 1315	Pass	N/S	-	Pass	
19	HP	PSC 1610	Pass	Pass	-	Pass	
20	HP	PSC 2510	Pass	Pass	-	Pass	
21	Lexmark	E120	Pass	N/A	-	Pass	
22	Lexmark	P6250	Pass	Pass	-	Pass	
23	Lexmark	X1270	Pass	N/A	-	Pass	
24	Lexmark	X2650	Pass	N/A	-	Pass	
25	Lexmark	X3470	N/S	-	-	N/S	
26	Lexmark	X3550	N/S	N/S	-	N/S	
27	Lexmark	X4270	N/S	Pass	-	Pass	
28	Lexmark	X7350	N/S	-	-	N/S	
29	Samsung	ML-2010	Pass	N/A	-	N/S	
30	Samsung	SCX-4500	Pass	Pass	-	Pass	

N/A : This USB Device does not have this function
 - : Not Test (Only a certain function of this device was tested)

N/S: This function is not supported.

Remark:

1. Scan: Pass* means pass either by Utility Scan or MS Paint Scan
2. Tested with driver version 2009_10_06

MFP / Printer / Scanner											Update : 01/25/2010
No	Brand	Model Name	XP				Windows Vista / Windows 7				
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*	
1	Avision	MF3230	Pass	Pass*	N/A	Pass	Pass	Pass*	N/A	Pass	
2	BenQ	CM3000	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A	
3	BenQ	CM3500	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A	
4	Brother	HL 2040	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass	
5	Brother	HL 5250DN	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass	
6	Brother	MFC-3320cn	Pass	N/A	-	Pass	Pass	Pass*	Pass	Pass	
7	Brother	MFC-3820cn	Pass	Pass	-	Pass	Pass	Pass	-	Pass	
8	Brother	MFC-240C	Pass	Pass	Pass	Pass	-	N/A	-	Pass	
9	Brother	MFC-7420	Pass	Pass	N/A	Pass	Pass	Pass*	N/A	Pass	
10	Canon	CanonScan Lide 5.0	N/A	Pass	N/A	-	N/A	Pass	N/A	-	
11	Canon	ImageClass MF3110	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass	
12	Canon	ImageClass MF3112	-	-	-	Pass	-	-	-	Pass	
13	Canon	ImageClass MF3220	-	-	-	Pass	-	-	-	Pass	
14	Canon	ImageClass MF3222	-	-	-	Pass	-	-	-	Pass	
15	Canon	ImageClass MF4010	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass	
16	Canon	ImageClass MF4150	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass	
17	Canon	iP100	-	-	-	Pass	-	-	-	Pass	
18	Canon	iP1700	Pass	N/A	N/A	-	Pass	N/A	N/A	-	
19	Canon	iP2500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass	
20	Canon	iP2600	Pass	N/A	N/A	-	Pass	N/A	N/A	-	
21	Canon	iP3300	Pass	N/A	N/A	-	Pass	N/A	N/A	-	
22	Canon	iP3500	Pass	N/A	N/A	-	Pass	N/A	N/A	-	
23	Canon	iP3600	Pass	N/A	N/A	-	Pass	N/A	N/A	-	
24	Canon	iP4200	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass	
25	Canon	iP4300	Pass	N/A	N/A	-	-	N/A	N/A	-	
26	Canon	iP4500	Pass	N/A	N/A	-	Pass	N/A	N/A	-	
27	Canon	iP4600	Pass	N/A	N/A	-	Pass	N/A	N/A	-	
28	Canon	iP5000	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass	
29	Canon	iP6700D	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass	
30	Canon	iP7500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass	
31	Canon	iP90	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass	
32	Canon	iP90v	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass	
33	Canon	iX5000	Pass	N/A	N/A	-	Pass	N/A	N/A	-	
34	Canon	LBP 1100	Pass	N/A	N/A	NS	N/A	N/A	N/A	N/A	
35	Canon	LBP 3200	N/A	N/A	N/A	N/A	Pass	N/A	N/A	N/A	
36	Canon	LBP 3300	N/A	N/A	N/A	N/A	Pass	N/A	N/A	N/A	
37	Canon	LBP 3700	Pass	N/A	N/A	Pass	N/A	N/A	N/A	N/A	

No	Brand	Model Name	XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
38	Canon	MP110	-	-	-	Pass	-	-	-	Pass
39	Canon	MP130	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
40	Canon	MP145	-	-	-	Pass	-	-	-	Pass
41	Canon	MP150	Pass	Pass	N/A	Pass	-	-	N/A	Pass
42	Canon	MP160	-	-	-	Pass	-	-	-	Pass
43	Canon	MP170	-	-	-	Pass	-	-	-	Pass
44	Canon	MP180	-	-	-	Pass	-	-	-	Pass
45	Canon	MP450	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
46	Canon	MP460	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
47	Canon	MP470	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
48	Canon	MP480	Pass	Pass	Pass	-	Pass	Pass	Pass	-
49	Canon	MP510	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
50	Canon	MP520	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
51	Canon	MP540	Pass	Pass	Pass	-	Pass	Pass	Pass	-
52	Canon	MP600	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
53	Canon	MP610	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
54	Canon	MP620	Pass	Pass	Pass	-	Pass	Pass	Pass	-
55	Canon	MP630	Pass	Pass	Pass	-	Pass	Pass	Pass	-
56	Canon	MP730	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
57	Canon	MP780	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
58	Canon	MP810	Pass	Pass	-	Pass	-	-	-	Pass
59	Canon	MP830	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
60	Canon	MP960	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
61	Canon	MP970	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
62	Canon	MP980	Pass	Pass	Pass	-	Pass	Pass	Pass	-
63	Canon	MX308	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
64	Canon	MX700	-	-	-	Pass	-	-	-	Pass
65	Canon	MX7600	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
66	Canon	MX850	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
67	Canon	Pixus 990i	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
68	Canon	Pro9000	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
69	Canon	Pro9000 Mark II	Pass	N/A	N/A	-	Pass	N/A	N/A	-
70	Canon	Pro9500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
71	Canon	Pro9500 Mark II	Pass	N/A	N/A	-	Pass	N/A	N/A	-
72	Dell	Photo 720	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
73	Epson	AL-C900	Pass	N/A	N/A	Pass	N/A	N/A	N/A	Pass
74	Epson	EPL-5800	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
75	Epson	EPL-6200L	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
76	Epson	EPL-N2500	Pass	N/A	N/A	Pass	N/A	N/A	N/A	Pass
77	Epson	LP 2500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass

No	Brand	Model Name	XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
78	Epson	Perfection 1270	N/A	Pass	N/A	-	N/A	Pass	N/A	-
79	Epson	PM-100	Pass	N/A	N/A	Pass	-	N/A	N/A	Pass
80	Epson	PM-3700C	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
81	Epson	PM-A840	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
82	Epson	PM-A840S	-	-	-	Pass	-	-	-	Pass
83	Epson	PM-A950	Pass	N/A	Pass	Pass	Pass	N/A	Pass	Pass
84	Epson	PM-G4500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
85	Epson	PM-G5300	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
86	Epson	PM-G860	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
87	Epson	PM-T940	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
88	Epson	PM-T960	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
89	Epson	PM-T990	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
90	Epson	PX-501A	-	-	-	Pass	-	-	-	Pass
91	Epson	PX-5600	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
92	Epson	PX-5800	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
93	Epson	PX-A640	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
94	Epson	PX-A740	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
95	Epson	PX-FA700	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
96	Epson	PX-V780	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
97	Epson	Stylus C43UX	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
98	Epson	Stylus C45	Pass	N/A	N/A	Pass	-	N/A	N/A	Pass
99	Epson	Stylus C60	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
100	Epson	Stylus C61	-	-	-	Pass	-	-	-	Pass
101	Epson	Stylus C65	-	-	-	Pass	-	-	-	Pass
102	Epson	Stylus C66	Pass	N/A	N/A	Pass	-	N/A	N/A	Pass
103	Epson	Stylus C67	-	-	-	Pass	-	-	-	Pass
104	Epson	Stylus C90	-	-	-	Pass	-	-	-	Pass
105	Epson	Stylus Color 670	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
106	Epson	Stylus CX2900	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
107	Epson	Stylus CX3500	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
108	Epson	Stylus CX3700	-	-	-	Pass	-	-	-	Pass
109	Epson	Stylus CX3810	Pass	Pass	N/A	Pass	-	-	N/A	Pass
110	Epson	Stylus CX3900	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
111	Epson	Stylus CX4700	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
112	Epson	Stylus CX4800	Pass	-	-	Pass	-	-	-	Pass
113	Epson	Stylus CX4900	Pass	Pass	-	-	Pass	Pass	-	-
114	Epson	Stylus CX9300F	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
115	Epson	Stylus Photo 1270	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
116	Epson	Stylus Photo 2200	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
117	Epson	Stylus Photo 830	Pass	N/A	N/A	Pass	-	N/A	N/A	-

No	Brand	Model Name	XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
118	Epson	Stylus Photo 915	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
119	Epson	Stylus R310	Pass	N/A	Pass	Pass	Pass	N/A	Pass	Pass
120	Epson	Stylus R320	Pass	N/A	Pass	Pass	-	N/A	Pass	Pass
121	Epson	Stylus RX510	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
122	Epson	Stylus RX530	Pass	Pass	Pass	-	Pass	Pass	Pass	Pass
123	Epson	Stylus RX590	Pass	Pass	Pass	-	-	-	-	-
124	HP	Deskjet 1125C	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
125	HP	Deskjet 1180C	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
126	HP	Deskjet 1220C	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
127	HP	Deskjet 3745	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
128	HP	Deskjet 5652	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
129	HP	Deskjet 640C	Pass	N/A	N/A	Pass	N/A	N/A	N/A	Pass
130	HP	Deskjet 830C	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
131	HP	Deskjet 920C	Pass	N/A	N/A	-	Pass	N/A	N/A	-
132	HP	Deskjet D2360	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
133	HP	Deskjet D2460	-	-	-	Pass	-	-	-	Pass
134	HP	Deskjet D3745	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
135	HP	Deskjet D4160	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
136	HP	Deskjet D4260	-	-	-	Pass	-	-	-	Pass
137	HP	Deskjet F300	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
138	HP	Deskjet F340	-	-	-	Pass	-	-	-	Pass
139	HP	Deskjet F350	-	-	-	Pass	-	-	-	Pass
140	HP	Deskjet F370	-	-	-	Pass	-	-	-	Pass
141	HP	Deskjet F379	-	-	-	Pass	-	-	-	Pass
142	HP	Deskjet F380	-	-	-	Pass	-	-	-	Pass
143	HP	Deskjet F4185	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
144	HP	LaserJet 1000	Pass	N/A	N/A	-	N/A	N/A	N/A	-
145	HP	LaserJet 1010	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
146	HP	LaserJet 1015	-	-	-	Pass	-	-	-	N/A
147	HP	LaserJet 1018	Pass	N/A	N/A	NS	Pass	N/A	N/A	NS
148	HP	LaserJet 1020	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
149	HP	LaserJet 1022	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
150	HP	LaserJet 1160	Pass	N/A	N/A	NS	Pass	N/A	N/A	NS
151	HP	LaserJet 2420	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
152	HP	LaserJet 2600n	Pass	N/A	N/A	-	-	N/A	N/A	-
153	HP	LaserJet 3015	Pass	Pass	N/A	-	Pass	Pass	N/A	-
154	HP	LaserJet 3030	Pass	-	-	Pass	-	-	-	Pass
155	HP	LaserJet 3050	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
156	HP	LaserJet 3050z	-	-	-	Pass	-	-	-	Pass
157	HP	LaserJet 3330	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass

MFP / Printer / Scanner

Update : 01/25/2010

No	Brand	Model Name	XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
158	HP	LaserJet 3380	-	-	-	Pass	-	-	-	NS
159	HP	LaserJet M1005	Pass	Pass	N/A	N/A	Pass	Pass	N/A	Pass
160	HP	Officejet 4255	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
161	HP	Officejet 5510	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
162	HP	Officejet 5610	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
163	HP	Officejet 6210	Pass	Pass	N/A	-	Pass	Pass	N/A	-
164	HP	Officejet 7210	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
165	HP	Officejet G85	Pass	Pass	N/A	-	Pass	Pass	N/A	-
166	HP	Officejet Pro L7380	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
167	HP	PhotoSmart 2610	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
168	HP	PhotoSmart 3110	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
169	HP	PhotoSmart 3210	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
170	HP	PhotoSmart 3310	-	-	-	Pass	-	-	-	Pass
171	HP	PhotoSmart 335	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
172	HP	PhotoSmart 7830	Pass	N/A	Pass	Pass	Pass	N/A	Pass	Pass
173	HP	PhotoSmart 8030	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
174	HP	PhotoSmart A310	Pass	N/A	N/A	-	Pass	N/A	N/A	-
175	HP	PhotoSmart C3180	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
176	HP	PhotoSmart C5280	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
177	HP	PhotoSmart P1000	Pass	N/A	Pass	-	N/A	N/A	Pass	-
178	HP	PSC 1210	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
179	HP	PSC 1315	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
180	HP	PSC 1350	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
181	HP	PSC 1402	-	-	-	Pass	-	-	-	Pass
182	HP	PSC 1410	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
183	HP	PSC 1510	-	-	-	Pass	-	-	-	Pass
184	HP	PSC 1610	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
185	HP	PSC 2210 All-in-one	Pass	Pass	-	-	Pass	Pass	-	-
186	HP	PSC 2410 All-in-one	-	-	-	Pass	-	-	-	Pass
187	HP	PSC 2510 All-in-one	Pass	Pass	-	Pass	Pass	Pass	-	Pass
188	HP	Scanjet 4200C	N/A	Pass	N/A	-	N/A	Pass*	N/A	-
189	HP	Scanjet 4370	N/A	NS	N/A	-	N/A	NS	N/A	-
190	IBM	Infoprint 1332	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
191	Konica Minota	MC-2430DL	Pass	N/A	N/A	-	-	N/A	N/A	-
192	Konica Minota	Page Pro 1350W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
193	Lexmark	E120	Pass	N/A	N/A	-	Pass	N/A	N/A	-
194	Lexmark	P4350	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
195	Lexmark	P6250	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
196	Lexmark	X1270	Pass	Pass*	N/A	NS	Pass	Pass*	N/A	NS
197	Lexmark	X2250	Pass	Pass	N/A	N/A	Pass	Pass	N/A	Pass

No	Brand	Model Name	XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
198	Lexmark	X2650	Pass	Pass	-	NS	Pass	Pass	-	NS
199	Lexmark	X3350	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
200	Lexmark	X3470	Pass	Pass*	Pass	NS	Pass	Pass*	Pass	NS
201	Lexmark	X3550	Pass	Pass*	Pass	NS	Pass	Pass*	Pass	NS
202	Lexmark	X4270	Pass	Pass	-	NS	Pass	Pass	-	NS
203	Lexmark	X5150	Pass	Pass	N/A	-	Pass	Pass*	N/A	-
204	Lexmark	X5470	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
205	Lexmark	X5495	Pass	Pass	-	-	Pass	Pass	-	-
206	Lexmark	X6170	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
207	Lexmark	X7350	Pass	Pass*	N/A	NS	Pass	Pass*	N/A	NS
208	Lexmark	X8350	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
209	Lexmark	Z1350	Pass	-	-	-	Pass	-	-	-
210	Lexmark	Z43	Pass	N/A	N/A	Pass	N/A	N/A	N/A	N/A
211	Lexmark	Z55	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
212	Lexmark	Z705	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
213	OKI	B4350	N/A	N/A	N/A	N/A	Pass	N/A	N/A	Pass
214	Samsung	ML-1710	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
215	Samsung	ML-1750	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
216	Samsung	ML-2010	Pass	N/A	N/A	Pass	Pass	N/A	N/A	NS
217	Samsung	SCX 4016	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
218	Samsung	SCX 4500	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass

N/A : This USB Device does not have this function
 - : Not Test (Only a certain function of this device was tested)
 NS: This function is not supported.

Remark:

1. Scan: Pass* means pass either by Utility Scan or MS Paint Scan

Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others Update : 01/25/2010

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
Hard Disk							
1	Airlink	USB Enclosure (AEN-U55)	Pass	Pass	-	-	
2	Benq	EW1621	Pass	Pass	-	-	
3	Buffalo	HD-PH80U2/UC-BK	Pass	Pass	Pass	Pass	
4	Corega	CG-U2HDC25	Pass	Pass	-	-	
5	Cypress	Cypress Semiconductor USB2.0 Storage	Pass	Pass	Pass	Pass	
6	Edge	EDGDC-196318-PE DiskGO 20GB USB HDD	Pass	Pass	Pass	Pass	
7	Genuine	Scopio	Pass	Pass	-	-	
8	Hitachi	2.5" USB HDD	Pass	Pass	Pass	Pass	
9	Initio	MHW2160BH PL	Pass	Pass	Pass	Pass	
10	IO Data	HDPG-SU80	Pass	Pass	-	-	
11	IOGear	eSATA/USB2.0	Pass	Pass	Pass	Pass	
12	IOGear	Firewire / USB 2.0 External HDD	Pass	Pass	NS	NS	
13	Jmicron	USB to ATA/ATAPI Bridge	Pass	Pass	Pass	Pass	
14	Logitec	LHD-ED1000FU2	Pass	Pass	Pass	Pass	
15	Logitec	LHD-ED1000SAU2	Pass	Pass	Pass	Pass	
16	Logitec	LHD-ED1000U2	Pass	Pass	Pass	Pass	
17	Logitec	LHD-ED250FU2	Pass	Pass	Pass	Pass	
18	Logitec	LHD-ED250SAU2	Pass	Pass	Pass	Pass	
19	Logitec	LHD-ED250U2	Pass	Pass	Pass	Pass	
20	Logitec	LHD-ED300FU2	Pass	Pass	Pass	Pass	
21	Logitec	LHD-ED300U2	Pass	Pass	Pass	Pass	
22	Logitec	LHD-ED320SAU2	Pass	Pass	Pass	Pass	
23	Logitec	LHD-ED320U2	Pass	Pass	Pass	Pass	
24	Logitec	LHD-ED400FU2	Pass	Pass	Pass	Pass	
25	Logitec	LHD-ED400SAU2	Pass	Pass	Pass	Pass	
26	Logitec	LHD-ED400U2	Pass	Pass	Pass	Pass	
27	Logitec	LHD-ED500FU2	Pass	Pass	Pass	Pass	
28	Logitec	LHD-ED500SAU2	Pass	Pass	Pass	Pass	
29	Logitec	LHD-ED500U2	Pass	Pass	Pass	Pass	
30	Logitec	LHD-ED640FU2	Pass	Pass	Pass	Pass	
31	Logitec	LHD-ED640SAU2	Pass	Pass	Pass	Pass	
32	Logitec	LHD-ED640U2	Pass	Pass	Pass	Pass	
33	Logitec	LHD-ED750FU2	Pass	Pass	Pass	Pass	
34	Logitec	LHD-ED750SAU2	Pass	Pass	Pass	Pass	
35	Logitec	LHD-ED750U2	Pass	Pass	Pass	Pass	
36	Logitec	LHD-HB250FU2	Pass	Pass	Pass	Pass	
37	Logitec	LHD-HB250U2	Pass	Pass	Pass	Pass	
38	Logitec	LHD-HB300FU2	Pass	Pass	Pass	Pass	

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
39	Logitech	LHD-HB300U2	Pass	Pass	Pass	Pass	
40	Logitech	LHD-HB320FU2	Pass	Pass	Pass	Pass	
41	Logitech	LHD-HB320U2	Pass	Pass	Pass	Pass	
42	Logitech	LHD-HB400FU2	Pass	Pass	Pass	Pass	
43	Logitech	LHD-HB400U2	Pass	Pass	Pass	Pass	
44	Logitech	LHD-HB500FU2	Pass	Pass	Pass	Pass	
45	Logitech	LHD-HB500U2	Pass	Pass	Pass	Pass	
46	Logitech	LHD-HB750FU2	Pass	Pass	Pass	Pass	
47	Logitech	LHD-HB750U2	Pass	Pass	Pass	Pass	
48	Logitech	LHD-HBS1000U2	Pass	Pass	Pass	Pass	
49	Logitech	LHD-HBS250FU2	Pass	Pass	Pass	Pass	
50	Logitech	LHD-HBS250SAU2	Pass	Pass	Pass	Pass	
51	Logitech	LHD-HBS250U2	Pass	Pass	Pass	Pass	
52	Logitech	LHD-HBS300FU2	Pass	Pass	Pass	Pass	
53	Logitech	LHD-HBS300SAU2	Pass	Pass	Pass	Pass	
54	Logitech	LHD-HBS300U2	Pass	Pass	Pass	Pass	
55	Logitech	LHD-HBS320FU2	Pass	Pass	Pass	Pass	
56	Logitech	LHD-HBS320SAU2	Pass	Pass	Pass	Pass	
57	Logitech	LHD-HBS320U2	Pass	Pass	Pass	Pass	
58	Logitech	LHD-HBS400FU2	Pass	Pass	Pass	Pass	
59	Logitech	LHD-HBS400SAU2	Pass	Pass	Pass	Pass	
60	Logitech	LHD-HBS400U2	Pass	Pass	Pass	Pass	
61	Logitech	LHD-HBS500FU2	Pass	Pass	Pass	Pass	
62	Logitech	LHD-HBS500SAU2	Pass	Pass	Pass	Pass	
63	Logitech	LHD-HBS500U2	Pass	Pass	Pass	Pass	
64	Logitech	LHD-HBS640U2	Pass	Pass	Pass	Pass	
65	Logitech	LHD-HBS750FU2	Pass	Pass	Pass	Pass	
66	Logitech	LHD-HBS750SAU2	Pass	Pass	Pass	Pass	
67	Logitech	LHD-HBS750U2	Pass	Pass	Pass	Pass	
68	Logitech	LHD-PBE120U2BK	Pass	Pass	Pass	Pass	
69	Logitech	LHD-PBE120U2SV	Pass	Pass	Pass	Pass	
70	Logitech	LHD-PBE120U2WH	Pass	Pass	Pass	Pass	
71	Logitech	LHD-PBE160U2BK	Pass	Pass	Pass	Pass	
72	Logitech	LHD-PBE160U2SV	Pass	Pass	Pass	Pass	
73	Logitech	LHD-PBE160U2WH	Pass	Pass	Pass	Pass	
74	Logitech	LHD-PBE40U2BK	Pass	Pass	Pass	Pass	
75	Logitech	LHD-PBE40U2SV	Pass	Pass	Pass	Pass	
76	Logitech	LHD-PBE40U2WH	Pass	Pass	Pass	Pass	
77	Logitech	LHD-PBE80U2BK	Pass	Pass	Pass	Pass	
78	Logitech	LHD-PBE80U2SV	Pass	Pass	Pass	Pass	
79	Logitech	LHD-PBE80U2WH	Pass	Pass	Pass	Pass	
80	Logitech	LHD-PBF120FU2SV	Pass	Pass	Pass	Pass	

No	Brand	Model Name	XP		VISTA		Remark
			Read	Write	Read	Write	
81	Logitech	LHD-PBF160FU2SV	Pass	Pass	Pass	Pass	
82	Logitech	LHD-PBF250FU2SV	Pass	Pass	Pass	Pass	
83	Logitech	LHD-PBF320FU2SV	Pass	Pass	Pass	Pass	
84	Logitech	LHD-PHA120FU2	Pass	Pass	Pass	Pass	
85	Logitech	LHD-PHA120U2	Pass	Pass	Pass	Pass	
86	Logitech	LHD-PHA160FU2	Pass	Pass	Pass	Pass	
87	Logitech	LHD-PHA160U2	Pass	Pass	Pass	Pass	
88	Logitech	LHD-PHA80FU2	Pass	Pass	Pass	Pass	
89	Logitech	LHD-PHA80U2	Pass	Pass	Pass	Pass	
90	Logitech	LHD-PS80U2WH	Pass	Pass	Pass	Pass	
91	Logitech	LHD-PSA120U2SV	Pass	Pass	Pass	Pass	
92	Mastor	Mastor Basics External Hard Drive (250G)	Pass	Pass	Pass	Pass	
93	Mastor	Mastor Basics External Hard Drive (500G)	Pass	Pass	Pass	Pass	
94	Mobile Disk	HD-338-U2C	Pass	Pass	-	-	
95	NetDisk	NDAS ND10	Pass	Pass	-	-	
96	NuSLIM	PL-2506	Pass	Pass	-	-	
97	Philips	Mobile Storage Drive (300G)	Pass	Pass	Pass	Pass	
98	Philips	USB 2.0 Mobile Disk (SPD5220CC/96S)	Pass	Pass	Pass	Pass	
99	Prolific	Prolific Technology ING (160G)	Pass	Pass	Pass	Pass	
100	RDC	RDC2882	Pass	Pass	-	-	
101	Sunplus	USB to Serial-ATA Bridge	Pass	Pass	Pass	Pass	
102	Teac	HD-231	Pass	Pass	-	-	
103	Transcend	2.5" HDD	Pass	Pass	Pass	Pass	
104	Transcend	StoreJet 2.5" 120G HDD	Pass	Pass	Pass	Pass	
105	Transcend	StoreJet 25C 320GB	Pass	Pass	Pass	Pass	
106	Transcend	StoreJet TS30GSJ18 30GB USB HDD	Pass	Pass	Pass	Pass	
107	Transcend	StoreJet TS40GSJ25B USB HDD	Pass	Pass	Pass	Pass	
108	Vantec	Nexstar.3 External 3.5" Hard Drive Enclosure	Pass	Pass	Pass	Pass	
109	VIA	USB to IDE Bridge	Pass	Pass	Pass	Pass	
110	Vipower	VPA-25289	Pass	Pass	-	-	
111	Xander	X-Note 2.5" 160G SATA Mobile Disk(Black)	Pass	Pass	Pass	Pass	
112	Zynet	HD-D4-U2SA	Pass	Pass	Pass	Pass	
113	Zynet	HD-D5-U2FW	Pass	Pass	Pass	Pass	
Card Reader							
114	Alcor	Single Slot SD/MMC/SD-HC Card Reader	Pass	Pass	Pass	Pass	
115	Elecom	MR-A10BK	Pass	Pass	Pass	Pass	
116	Elecom	MR-A10GN	Pass	Pass	Pass	Pass	
117	Elecom	MR-A10GY	Pass	Pass	Pass	Pass	
118	Elecom	MR-A10WH	Pass	Pass	Pass	Pass	
119	Elecom	MR-A11HWH	Pass	Pass	Pass	Pass	
120	Elecom	MR-A13HSV	Pass	Pass	Pass	Pass	
121	Elecom	MR-A14HBK	Pass	Pass	Pass	Pass	

No	Brand	Model Name	XP		VISTA		Remark
			Read	Write	Read	Write	
122	Elecom	MR-A14HBU	Pass	Pass	Pass	Pass	
123	Elecom	MR-A14HSV	Pass	Pass	Pass	Pass	
124	Elecom	MR-A14HWH	Pass	Pass	Pass	Pass	
125	Elecom	MR-A20HBK	Pass	Pass	Pass	Pass	
126	Elecom	MR-A20HBU	Pass	Pass	Pass	Pass	
127	Elecom	MR-A20HRD	Pass	Pass	Pass	Pass	
128	Elecom	MR-A20HSV	Pass	Pass	Pass	Pass	
129	Elecom	MR-A20HWH	Pass	Pass	Pass	Pass	
130	Elecom	MR-A33HBK	Pass	Pass	Pass	Pass	
131	Elecom	MR-A33HSV	Pass	Pass	Pass	Pass	
132	Elecom	MR-A33HWH	Pass	Pass	Pass	Pass	
133	Elecom	MR-A47HBK	Pass	Pass	Pass	Pass	
134	Elecom	MR-A47HSV	Pass	Pass	Pass	Pass	
135	Elecom	MR-A47HWH	Pass	Pass	Pass	Pass	
136	Elecom	MR-C10BK	Pass	Pass	Pass	Pass	
137	Elecom	MR-C10SV	Pass	Pass	Pass	Pass	
138	Elecom	MR-C10WH	Pass	Pass	Pass	Pass	
139	Elecom	MR-C11BK	Pass	Pass	Pass	Pass	
140	Elecom	MR-C11RD	Pass	Pass	Pass	Pass	
141	Elecom	MR-C11SV	Pass	Pass	Pass	Pass	
142	Elecom	MR-C11WH	Pass	Pass	Pass	Pass	
143	Elecom	MR-C12BK	Pass	Pass	Pass	Pass	
144	Elecom	MR-C12BU	Pass	Pass	Pass	Pass	
145	Elecom	MR-C12RD	Pass	Pass	Pass	Pass	
146	Elecom	MR-C12WH	Pass	Pass	Pass	Pass	
147	Elecom	MR-C13BK	Pass	Pass	Pass	Pass	
148	Elecom	MR-C13WH	Pass	Pass	Pass	Pass	
149	Elecom	MR-SMC01BK	Pass	Pass	Pass	Pass	
150	Elecom	MR-SSD01BK	Pass	Pass	Pass	Pass	
151	E-Sense	SCR200	Pass	Pass	Pass	Pass	
152	Galileo	23-in-1 Card Reader	Pass	Pass	-	-	
153	Genesys	SD Card Reader Genesys Logic	Pass	Pass	Pass	Pass	
154	Moai	SDMMC M121	Pass	Pass	Pass	Pass	
155	Myson Century	CF Card Reader USB2.0	Pass	Pass	Pass	Pass	
156	No Brand	6 in 1 Card Reader (CR-V1102-U26)	Pass	Pass	Pass	Pass	
157	No Brand	Media Reader USB 2.0	Pass	Pass	Pass	Pass	
158	Philips	SD/Mini SD/MMC Card Reader	Pass	Pass	Pass	Pass	
159	Samsung	TRUTION TUH-7000X	Pass	Pass	-	-	
160	SanDisk	SDDR-113	Pass	Pass	Pass	Pass	
161	Sanwa	ADR-MLT1W	Pass	Pass	Pass	Pass	
162	SMSC	USB to Flash Device	Pass	Pass	Pass	Pass	
163	SUNZone	SUZCR920	Pass	Pass	N/A	N/A	

No	Brand	Model Name	XP		VISTA		Remark
			Read	Write	Read	Write	
164	Teac	US-4SM-B	Pass	Pass	-	-	
165	Transcend	TS-RD13B, 13-in-1 Card Reader	Pass	Pass	-	-	
166	VIA	USB2.0 Card Reader	Pass	Pass	Pass	Pass	
VCD / DVD RW							
167	Benq	DVD-RW (EW-1621)	Pass	Pass	Pass	Pass	
168	Benq	DVD-RW (EW-164B)	Pass	Pass	Pass	Pass	
169	Buffalo	DVD Writer (DVSM-XL1218U2)	Pass	Pass	Pass	Pass	
170	IO Data	DVR-UEM16CR	Pass	Pass	-	-	
171	Logitech	LDR-MA18U2	Pass	Pass	-	-	
172	Logitech	LDR-PMD8U2	Pass	Pass	Pass	Pass	
173	Pioneer	Pioneer MULTI Recorder	Pass	Pass	Pass	Pass	
174	Sony	DRX-100UL	Pass	Pass	-	-	
MP3							
175	Apia	APIA MP3 Player	Pass	Pass	Pass	Pass	
176	Apple	iPod 30G	Pass	Pass	Pass	Pass	
177	Apple	iPod Mini	Pass	Pass	-	-	
178	Apple	iPod Video	Pass	Pass	Pass	Pass	
179	Apple	iPod shuffle	-	-	-	-	
180	Apple	iPod nano	-	-	-	-	
181	Apple	iPod classic	-	-	-	-	
182	Apple	iPod touch	-	-	-	-	
183	Apple	iPhone 2G	-	-	-	-	
184	Apple	iPhone 3G	-	-	-	-	
185	Greative	MuVO TX FM	Pass	Pass	Pass	Pass	
186	Isito	IS-901B	Pass	Pass	Pass	Pass	
187	MP4 digital player	F630	Pass	Pass	Pass	Pass	
188	Mpio	FG100	Pass	Pass	Pass	Pass	
189	Samsung	YP-E3 MP3 Player	Pass	Pass	Pass	Pass	
190	Sony	NW-A806	Pass	Pass	Pass	Pass	
191	Sony	NWD-B103F	Pass	Pass	Pass	Pass	
192	Sony	NW-E013	Pass	Pass	Pass	Pass	
193	Sony	NWZ-S615F	Pass	Pass	Pass	Pass	
Flash Drive							
194	Adata	MyFlash USB2.0 1GB	Pass	Pass	-	-	
195	Adata	MyFlash USB2.0 512MB RB15	Pass	Pass	-	-	
196	Apacer	Handy	Pass	Pass	Pass	Pass	
197	Buffalo	RUF2-S512-BK	Pass	Pass	-	-	
198	Elecom	USB Flash 128MB	Pass	Pass	-	-	
199	IO Data	ToteBag TB-BH512/B	Pass	Pass	-	-	
200	Kingston	DataTraveler 1GB	Pass	Pass	Pass	Pass	
201	Kingston	DataTraveler 2.0 1GB	Pass	Pass	Pass	Pass	
202	Lexar	FireFly (JDFF512-431)	Pass	Pass	-	-	

No	Brand	Model Name	XP		VISTA		Remark
			Read	Write	Read	Write	
203	PNY	PNY Attache 2.0	Pass	Pass	Pass	Pass	
204	Pqi	Flash Disk 1G	Pass	Pass	Pass	Pass	
205	SanDisk	Cruzer Contour 4G	Pass	Pass	Pass	Pass	
206	SanDisk	Cruzer Contour 8G	Pass	Pass	Pass	Pass	
207	SanDisk	Cruzer Micro 1G	Pass	Pass	Pass	Pass	
208	SanDisk	Cruzer Micro 4G	Pass	Pass	Pass	Pass	
209	SanDisk	Cruzer Mini 128M	Pass	Pass	Pass	Pass	
210	Slicon Power	Touch Series USB Flash Drive 1G	Pass	Pass	Pass	Pass	
211	Sony	POCKETBIT USM512J	Pass	Pass	-	-	
212	Sony	USM2GJ	Pass	Pass	Pass	Pass	
213	Sony	USM4GJX	Pass	Pass	Pass	Pass	
214	TD Star	TD Star USB Drive	Pass	Pass	Pass	Pass	
215	Transcend	JetFlash 1GB	Pass	Pass	Pass	Pass	
216	Transcend	JetFlash 512MB	Pass	Pass	Pass	Pass	
217	Transcend	JF130 1GB	Pass	Pass	Pass	Pass	
218	Transcend	JF168 1GB	Pass	Pass	Pass	Pass	
219	Transcend	JFV30 1GB	Pass	Pass	Pass	Pass	
Floppy Disk							
220	Acer	YD-8U10	Pass	Pass	Pass	Pass	
221	Mitsumi	D343GUE	Pass	Pass	Pass	Pass	
222	Mitsumi	D353FUE	Pass	Pass	Pass	Pass	
223	Mitsumi	USB FDD	Pass	Pass	Pass	Pass	
USB 2.0 Hub							
224	Adaptec	Hi-Speed 4 Ports USB HUB	Pass	Pass	Pass	Pass	
225	GoodTek	GH-201 USB 2.0 4 Ports Hub	Pass	Pass	Pass	Pass	
226	Hewlett-Packard	DG954A 4 Port USB2.0 HUB	Pass	Pass	-	-	
227	I-Rocks	IR-4370 Hub	Pass	Pass	Pass	Pass	
228	KINYO	HUB-3 Pro2007314211459	Pass	Pass	Pass	Pass	
229	No Brand	Mini 4 Ports Hub BP-07000153	Pass	Pass	Pass	Pass	
230	Nstyle	Chip: Genesys Logic Inc	Pass	Pass	Pass	Pass	
231	Samsung	Pleomax PUH-7000X	Pass	Pass	Pass	Pass	
Others							
232	DigiMatelll	INSTEP EX-SRIVE	Pass	Pass	Pass	Pass	Photo Bank
233	MagicPixel	MP612B	Pass*1	Pass*1	Pass*1	Pass*1	Photo Frame
228	Sony	PSP	Pass	Pass	Pass	Pass	PlayStation Portable

N/A : This USB Device does not have this function

- : Not Test (Only a certain function of this device was tested)

NS: This function is not supported.

Remark:

Pass*1: USB device signal issue, only at full speed.

USB Audio / USB Phone / USB Display / USB Webcam				Update : 01/25/2010	
No	Brand	Model Name	XP	Vista	
USB Audio					
1	3D Sound	PU552	Pass	Pass	
2	3D Sound	USB 2.0 3D Audio Sound Card Adapter Virtual 5.1 SC18	Pass	Pass	
3	Creative	Labs Sound Blaster Digital Music SX	Pass	Pass	
4	ESMT	USB Speaker USB-269A	Pass	Pass	
5	Genius	USB Audio Device	Pass	Pass	
6	Hewlett-Packard	Multi-media Speakers	Pass	Pass	
7	Intopic	Jazz USB Headphone Set	Pass	Pass	
8	JS	USB Speaker J-6502	Pass	Pass	
9	Kuro	USB Speaker KUP 700	Pass	Pass	
10	Lemel	USB Speaker	Pass	Pass	
11	Logitech	LRT-FMAM100U	Pass	Pass	
12	Logitech	V20 Notebook Speakers	Pass	Pass	
13	Mediatek	C-Media USB Headphone Set	Pass	Pass	
14	Samsung	USB-335E	Pass	Pass	
15	TI	TI USB Audio DAC	Pass	Pass	
16	Turtle Beach	Audio Advantage Micro	Pass	Pass	
USB Phone					
17	Aipotek	VP-0002	Pass	Pass	
18	Corega	Advanced USB Phone CG-USBPH02	Pass	Pass	
19	Ipevo	CDPU-04IP	Pass	Pass	
USB Display					
20	Asus	UF735	Pass	Pass	
21	DisplayLink	DL-120	Pass	Pass	
22	DisplayLink	DL-160	Pass	Pass	
23	Neonplus	USB2.0 VGA Adapter	Pass	Pass	
24	No Brand	UVT100	Pass	Pass	
USB WebCam					
25	Andymay	CD-06 (USB 2.0)	Pass	Pass	
26	Andymay	CD-07 (USB 1.1)	Pass	Pass	
27	Creative	Live!Cam Video IM Skype Edition (USB 1.1)	Pass	Pass	
28	Elecom	UCAM-DLM130	Pass	Pass	
29	Elecom	UCAM-DLM130HPN	Pass	Pass	
30	Elecom	UCAM-DLM130HSV	Pass	Pass	
31	Elecom	UCAM-DLM130HWH	Pass	Pass	
32	Elecom	UCAM-DLQ30	Pass	Pass	
33	Elecom	UCAM-DLS30HBK	Pass	Pass	
34	Elecom	UCAM-DLS30HPN	Pass	Pass	
35	Elecom	UCAM-DLS30HSV	Pass	Pass	
36	Elecom	UCAM-E130HBU	Pass	Pass	

USB Audio / USB Phone / USB Display / USB Webcam				Update : 01/25/2010
No	Brand	Model Name	XP	Vista
37	Elecom	UCAM-E130HSV	Pass	Pass
38	Elecom	UCAM-E130HWH	Pass	Pass
39	Elecom	UCAM-E130HWH	Pass	Pass
40	Empia	JHY107	Pass	Pass
41	Gdmall	Cyber Cam Max (USB 1.1)	Pass	Pass
42	Intopic	Web Live620-W (USB 2.0)	Pass	N/A
43	Intopic	Web Live660-G (USB 1.1)	Pass	Pass
44	Ipevo	Ipevo POV CDVU-02IP	Pass	Pass
45	Kinyo	My EZCam PCM-531 (USB 1.1)	Pass	Pass
46	Logitech	QuickCam Chat	Pass	Pass
47	Logitech	QuickCam Chat(USB 1.1)	Pass	N/A
48	Logitech	QuickCam Communication STX	Pass	Pass
49	Logitech	QuickCam Pro 3000	Pass	N/A
50	Microsoft	LifeCam VX-3000 (USB 1.1)	Pass	Pass
51	Microsoft	LifeCam VX-7000 (USB 2.0)	Pass	Pass
52	Nstyle	NWC-532 (USB 2.0)	Pass	Pass
53	ORITE	MB-630 (USB 1.1)	Pass	N/A
54	Philips	Webcam SPC500NC (USB 1.1)	Pass	Pass
55	Ronald	Digital Camera L-1 (PC222) (USB 2.0)	Pass	Pass
56	T.C.Star	TCB-P262 (USB 2.0)	Pass	Pass
57	T.C.Star	TCB-A322 (USB 2.0)	Pass	Pass
58	TASCORP	JPEG USB Video Camera (USB 1.1)	Pass	N/A
59	V-Gear	TalkCam Live AMVG1-010-063-02-G (USB 1.1)	Pass	Pass

N/A : This USB Device does not have this function
- : Not Test (Only a certain function of this device was tested)
NS: This function is not supported.

DV / DSC / Cell Phone							Update : 01/25/2010
No	Brand	Model Name	XP		Vista		
			Read	Write	Read	Write	
DV							
1	Sanyo	VPC-C4	Pass	Pass	-	-	
2	Sony	DCR-SR200	Pass	Pass	Pass	Pass	
3	Sony	DCR-SR300	Pass	Pass	Pass	Pass	
4	Sony	DCR-SR62	Pass	Pass	Pass	Pass	
5	Sony	DCR-SR82	Pass	Pass	Pass	Pass	
6	Sony	HDR-CX7	Pass	Pass	Pass	Pass	
7	Sony	HDR-CX7K	Pass	Pass	Pass	Pass	
8	Sony	HDR-SR5	Pass	Pass	Pass	Pass	
9	Sony	HDR-SR7	Pass	Pass	Pass	Pass	
10	Sony	HDR-SR8	Pass	Pass	Pass	Pass	
DSC							
11	AIPTEK	DV M2	Pass	Pass	Pass	Pass	
12	Canon	A640	Pass	Pass	Pass	Pass	
13	Canon	EOS 350D	Pass	Pass	-	-	
14	Canon	IXUS 400	Pass	Pass	-	-	
15	Canon	IXUS 500	Pass	Pass	Pass	Pass	
16	Canon	IXUS 65	Pass	Pass	Pass	Pass	
17	Canon	IXUS 860IS	Pass	Pass	Pass	Pass	
18	Canon	PowerShot A640	Pass	Pass	-	-	
19	Canon	PowerShot G5	Pass	Pass	Pass	Pass	
20	Canon	PowerShot S30	Pass	Pass	-	-	
21	Canon	PowerShot S3IS	Pass	Pass	-	-	
22	Canon	PowerShot S400	Pass	Pass	-	-	
23	Canon	Pro90IS	Pass	Pass	-	-	
24	Casio	Exilim EX-Z40	Pass	Pass	-	-	
25	Casio	Exilim EX-Z55	Pass	Pass	Pass	Pass	
26	Casio	QV-R62	Pass	Pass	-	-	
27	Fujifilm	FinePix A310	Pass	Pass	-	-	
28	Fujifilm	FinePix S5000	Pass	Pass	-	-	
29	Fujifilm	FinePix S602	Pass	Pass	-	-	
30	Fujifilm	FinePix S9500	Pass	Pass	Pass	Pass	
31	Kodak	CX6330	Pass	Pass	-	-	
32	Minolta	DiMAGE F200	Pass	Pass	Pass	Pass	
33	Minolta	DiMAGE Xt	Pass	Pass	-	-	
34	Nikon	Coolpix 3100	Pass	Pass	-	-	
35	Nikon	Coolpix 3200	Pass	Pass	-	-	
36	Nikon	Coolpix 5900	Pass	Pass	-	-	
37	Nikon	D100	Pass	Pass	-	-	
38	Nikon	D40	Pass	Pass	-	-	

DV / DSC / Cell Phone						pdate : 01/25/2010	
No	Brand	Model Name	XP		Vista		
			Read	Wirte	Read	Wirte	
39	Olympus	C-2	Pass	Pass	-	-	
40	Olympus	C-720	Pass	Pass	-	-	
41	Olympus	C-740	Pass	Pass	-	-	
42	Olympus	μ1000	Pass	Pass	-	-	
43	Olympus	μ300	Pass	Pass	-	-	
44	Olympus	μ410	Pass	Pass	-	-	
45	Panasonic	DMC FX1	Pass	Pass	Pass	Pass	
46	Panasonic	LUMIX F7 (DMC-F7)	Pass	Pass	-	-	
47	Panasonic	LUMIX FX7 (DMC-FX07GT)	Pass	Pass	-	-	
48	Panasonic	LUMIX FX9 (DMC-FX9)	Pass	Pass	-	-	
49	Panasonic	LUMIX FZ20 (DMC-FZ20)	Pass	Pass	-	-	
50	Panasonic	LUMIX LC33	Pass	Pass	-	-	
51	Panasonic	LUMIX LX2	Pass	Pass	-	-	
52	Pentax	OPTIO M10	Pass	Pass	-	-	
53	Richo	Caplio-R4	Pass	Pass	-	-	
54	Sony	DSC-H3	Pass	Pass	Pass	Pass	
55	Sony	DSC-H5	Pass	Pass	Pass	Pass	
56	Sony	DSC-H9	Pass	Pass	Pass	Pass	
57	Sony	DSC-P10	Pass	Pass	Pass	Pass	
58	Sony	DSC-P200	Pass	Pass	Pass	Pass	
59	Sony	DSC-T1	Pass	Pass	Pass	Pass	
60	Sony	DSC-T2	Pass	Pass	Pass	Pass	
61	Sony	DSC-T200	Pass	Pass	Pass	Pass	
62	Sony	DSC-T70	Pass	Pass	Pass	Pass	
63	Sony	DSC-T9	Pass	Pass	Pass	Pass	
64	Sony	DSC-W1	Pass	Pass	Pass	Pass	
65	Sony	DSC-W200	Pass	Pass	Pass	Pass	
66	Sony	DSC-W80	Pass	Pass	Pass	Pass	
67	Sony	DSLR-A200	Pass	Pass	Pass	Pass	
68	Sony	DSLR-A700	Pass	Pass	Pass	Pass	
69	Sony	NSC-GC1	Pass	Pass	Pass	Pass	
Cell Phone							
70	Nokia	6233	Pass	Pass	Pass	Pass	

N/A: This USB Device does not have this function
- : Not Test (Only a certain function of this device was tested) ;
NS: This function is not supported.

Mouse / Keyboard / Joystick			Jpdate : 01/25/2010	
No	Brand	Model Name	XP	Vista
Mouse				
1	Acer	GM-03024A	Pass	Pass
2	Acer	NB Mouse	Pass	Pass
3	DELL	M056U0	Pass	Pass
4	Detroit	PS/2 + USB Mouse	Pass	Pass
5	HP	M-UAE96	Pass	Pass
6	HP	M-UV94	Pass	Pass
7	IBM	USB Device 04B3	Pass	Pass
8	Lemel	M857C	Pass	Pass
9	Logitech	M-BB48	Pass	Pass
10	Logitech	M-BD53	Pass	Pass
11	Logitech	MX310	Pass	Pass
12	Logitech	USB Mouse M-UAG120	Pass	Pass
13	Logitech	USB Mouse M-UV94	Pass	Pass
14	Logitech	USB Optical Mouse	Pass	Pass
15	Microsoft	Compact Optical Mouse M-000008	Pass	Pass
16	Microsoft	Wheel Mouse Optical USB and PS/2 Compatible X08-71118	Pass	Pass
17	Microsoft	X800898	Pass	Pass
18	Samsung	Acrox USB & PS/2 Mouse	Pass	Pass
19	Samsung	Pleomax PS/2+ USB Mouse	Pass	Pass
Keyboard				
20	BTC	8113W	Pass	Pass
21	BTC	8193C	Pass	Pass
22	Hewlett-Packard	KU-0316	Pass	Pass
23	Intopic	KDB-USB-10W	Pass	-
24	No Brand	PS/2 Mouse & Keyboard Connertor to USB	Pass	Pass
Joystick				
25	DragonRise	Generic USB Joystick	Pass	Pass
26	Genesys	Genesys Logic	Pass	-
27	Logitech	Driving Force EX	Pass	Pass
28	Logitech	RumblePad 2 G-UF13	Pass	Pass
29	Logitech	WingMan Formula Force GP	Pass	Pass
30	Logitech	Wingman Strike Force 3D	Pass	Pass

N/A: This USB Device does not have this function
 - : Not Test (Only a certain function of this device was tested);
 NS: This function is not supported.

Support Limitation			Update : 01/25/2010
No	Brand	Model Name	
Bluetooth			
1	Gigabyte	Bluetooth USB Dongle	
Cell phone			
2	Dopod	585	
3	Dopod	818 Pro	
4	Nokia	6060	
5	Motorola	RAZR V3	
6	Sony Ericsson	W910i	
Scanner			
7	Canon	CanoScan 5200 F	
8	Pempower	WorldCard Ultra	
9	Hewlett-Packard	Scanjet 4370	